

Shower Controls

1. Locate the control lever positioned at the bottom and pull it towards you with the lever in the 7 o'clock position.
2. Initiate the water flow from the overhead shower by rotating the top control. Let the water run until it reaches a warm temperature.
3. Adjust the temperature to your preference by rotating the bottom control. If the water doesn't get warm enough at its maximum setting, consider turning on the immersion heater.
4. The remaining controls are for the upper body, lower body, and handheld spray.



Rotate for overhead shower.

Rotate for upper body jets.

Rotate for lower body jets.

Rotate for handheld spray

**Pull this lever forward to turn on.
Water will only flow when one of
the other controls is opened.
Rotate for a comfortable
temperature**